

- ChaiseLoungeer \* - Provides continuous, head-to-toe support when reclined.
- TouchMotion \* - Easily reclines at the touch of a button.
- PowerRecline \* - Effortlessly recline to your favorite position.
- Lighted Cupholder - Lighted ring illuminates the cupholder from the inside.
- ButtKicker \* - Silent subwoofer in seat that allows viewers to feel powerful bass without excessive volume.
- Wallaway \* - Fully reclines inches away from the wall, allowing greater decorating flexibility and more efficient use of space.

### 45" BACK HEIGHT ON ALL PIECES

