

- **Wallaway®** - Fully reclines inches away from the wall, allowing greater decorating flexibility and more efficient use of space.
- **TouchMotion®** - Easily reclines at the touch of a button.
- **ButtKicker®** - "Silent subwoofer" delivers a sound sensation you feel in the seat of your pants. Makes music and special effects come alive like never before.
- **PowerRecline®** - Effortlessly recline to your favorite position.
- **Cupholder** - Generously sized to hold most cans, bottles and drink cups. Decorative beveled rim for a finished look.
- **ChaiseLounger®** - Provides continuous, head-to-toe support when reclined.
- **Optional Lighted Cupholder** - Lighted ring illuminates the cupholder from the inside.

44.5" BACK HEIGHT

